

Spare part list

B 13/2 RLE 2-speed rotary drill

DUSS

Description	Order-No.	Quantity	Description	Order-No.	Quantity
Hexagon nut M5	B13-1	1	Motor housing	B13-49	1
Star knob	B13-2	1	Carbon brush	B13-50	2
Clamping collar	B13-3	1	Brush holder	B13-51	2
Side handle	B13-4	1	DUSS sticker	B13-52	2
Clamping collar, assembled	B13-4K	0	Reverser	B13-53	0
Nut M10	B13-5	1	Sticker R-L	B13-54	1
Depth stop	B13-6	1	Quick drill chuck	B13-55	1
Cap	B13-7	1			
Retaining screw	B13-8	1			
Tool bit driver	B13-9	1			
Retaining ring	B13-10	1			
Washer	B13-11	1			
Ball bearing	B13-12	1			
Retaining ring	B13-13	1			
Lens head screw 4x35	B13-14	2			
O-ring seal 10x1,5	B13-15	1			
Gearshift lever	B13-16	1			
Ball dia. 4mm	B13-17	1			
Spring	B13-18	1			
Countersunk head screw M5x8	B13-19	1			
Front cover	B13-20	1			
Spacer	B13-20a	1			
Lens head screw 4x62	B13-21	2			
Gasket	B13-22	1			
Sliding gear wheel	B13-23	1			
Ball bearing	B13-24	1			
Sliding pinion	B13-25	1			
O-ring seal 8x2	B13-26	1			
Ball bearing	B13-27	1			
Needle bearing	B13-28	3			
Second shaft	B13-29	1			
Pinion	B13-30	1			
Ball bearing	B13-31	1			
Gear cover	B13-32	1			
Ball bearing	B13-33	1			
Washer	B13-34	1			
Armature, 230V	B13-35	1			
Ball bearing	B13-36	1			
RFJ choke, blue	B13-37	1			
RFJ choke, black	B13-38	1			
Capacitor	B13-39	1			
Cord sleeve	B13-40	1			
Lens head screw 4x14	B13-41	6			
Cord clamp	B13-42	1			
Cord and plug	B13-43	1			
Baffle plate	B13-44	1			
Field, 230V	B13-45	1			
Lens head screw 4x48	B13-46	4			
B13/2RLE nameplate	B13-47	1			
Switch	B13-48	1			

DUSS

B 13/2 RLE

