

# Spare part list

## DIA 303 diamond core drill

# DUSS

Description	Order-No.	Quantity	Description	Order-No.	Quantity
Side handle	DIA303-1	1	Lens head screw 4x20	DIA303-73	3
Clamping collar with jaw	DIA303-2	1	Spring	DIA303-74	1
Nut M12	DIA303-3	1	Switch handle	DIA303-75	1
Cheese head screw M6x20	DIA303-4	4	Spacer	DIA303-76	4
Copper washer M6	DIA303-5	4	Cheese head screw M5x25	DIA303-77	4
Centring rod	DIA303-6	1	Fitting for the diodes	DIA303-78	1
Front cover	DIA303-7	1	Lens head screw 4x14	DIA303-79	2
Sealing ring	DIA303-8	1	Cord clamp	DIA303-80	1
Roller bearing	DIA303-9	1	Cord sleeve	DIA303-83	1
Sealing ring	DIA303-10	1	Side handle	DIA303-86	1
Gasket	DIA303-11	1	O-ring seal 8x3	DIA303-87	1
O-ring seal 12x2	DIA303-12	1	Nut M12	DIA303-88	1
Retaining ring	DIA303-17	1	Ball bearing	DIA303-95	5
Ball bearing	DIA303-18	1	Layshaft gear	DIA303-96	1
Support washer	DIA303-19	1	Pinion	DIA303-97	1
Retaining ring	DIA303-20	1	Idler gear 2	DIA303-98	1
Tool bit driver	DIA303-21	1	Idler pinion	DIA303-99	1
Roller 4x19,8	DIA303-22	10	Idler gear 1	DIA303-100	1
Roller 4x11,8	DIA303-23	14	V-ring seal	DIA303-101	1
Washer	DIA303-25	1	Distance ring	DIA303-102a	1
Inner clutch spring	DIA303-26	1	O-ring seal 26x2	DIA303-103	1
Outer clutch spring	DIA303-27	1	Plain washer	DIA303-104	1
Bevel gear	DIA303-28	1	Ball bearing	DIA303-105	1
Circlip	DIA303-29	1	Retaining ring	DIA303-106	1
Copper washer M5	DIA303-41	6	Washer	DIA303-107	1
Roller, small	DIA303-43	1	Armature, 230V	DIA303-108	1
Roller, large	DIA303-44	1	Ball bearing	DIA303-109	1
Roller 5x23,8	DIA303-45	1	Rubber sleeve	DIA303-110	1
Actuating shaft	DIA303-46	1	Ball bearing	DIA303-111	1
O-ring seal 17x2	DIA303-47	1	Spline shaft gear	DIA303-112	1
Change lever	DIA303-48	1	Spline shaft	DIA303-113	1
Cheese head screw M4x12	DIA303-49	1	Sliding gear 1	DIA303-114	1
Gasket	DIA303-50	1	Ball dia. 2mm	DIA303-115	2
Ball dia. 4mm	DIA303-51	1	Ball bearing	DIA303-116	2
Spring	DIA303-52	1	Sliding gear 2	DIA303-117	1
Countersunk head screw M5x8	DIA303-53	1	Sliding gear 3	DIA303-118	1
Cheese head screw M5x20	DIA303-57	6	O-ring seal 12x1	DIA303-119	2
Motor housing	DIA303-58	1	Needle bush	DIA303-120	1
Grooved pin	DIA303-59	4	Ball bearing	DIA303-121	1
Carbon brush AB with wire strand	DIA303-62	1	Ball bearing	DIA303-122	1
Brush holder	DIA303-63	2	Gear wheel	DIA303-123	1
Carbon brush	DIA303-64	1	Bevel gear pinion	DIA303-124	1
Lens head screw 3x10	DIA303-65	4	Lens head screw 4x48	DIA303-125	2
Ventilation insert, right	DIA303-66	1	Field, 230V	DIA303-126	1
Ventilation insert, left	DIA303-67	1	Insulating housing	DIA303-127	1
Electronics ass'y	DIA303-68	1	Motor cover	DIA303-128	1
Damper motor housing	DIA303-69	1	Lens head screw M4x20	DIA303-129	4
Damper cylinder housing	DIA303-70	1	Insulating sleeve	DIA303-131	1
Switch	DIA303-71	1	Retaining ring	DIA303-133	1
Potentiometer	DIA303-72	1	Retaining ring	DIA303-134	1

# Spare part list

## DIA 303 diamond core drill

# DUSS

Description	Order-No.	Quantity
Threaded nipple	DIA303-200	1
Sealing plug	DIA303-201	1
Gear housing	DIA303-202	1
DIA303 nameplate	DIA303-203	1

Description	Order-No.	Quantity
DUSS DIA303 sticker	DIA303-204	2
Cord and plug	DIA303-205	1

