

Spare part list

DIA 52 W diamond core drill

DUSS

Description	Order-No.	Quantity	Description	Order-No.	Quantity
Side handle	DIA52W-1	1	Washer	DIA52W-59	2
Clamping collar with jaw	DIA52W-2	1	Layshaft gear	DIA52W-60	1
Nut M12	DIA52W-3	1	Pinion	DIA52W-61	1
O-ring seal 28x3,5	DIA52W-4	1	Ball bearing	DIA52W-62	1
Adapter	DIA52W-5	1	Lens head screw 3x10	DIA52W-66	4
O-ring seal 7x2,5	DIA52W-6	2	Gasket	DIA52W-68	1
Water hose	DIA52W-7	1	Copper washer M5	DIA52W-69	7
Cheese head screw M6x20	DIA52W-8	4	Cheese head screw M5x20	DIA52W-70	6
Copper washer M6	DIA52W-9	4	Countersunk head screw M4x10	DIA52W-72	1
Front cover	DIA52W-10	1	Damper motor housing	DIA52W-75	2
Gasket	DIA52W-11	1	Spring	DIA52W-77	1
Sealing ring	DIA52W-12	1	Potentiometer	DIA52W-78	1
Sealing ring	DIA52W-12a	1	Choke coil	DIA52W-80	1
Roller bearing	DIA52W-13	1	Cord clamp	DIA52W-84	1
Washer	DIA52W-14	3	Lens head screw 4x14	DIA52W-85	4
Needle thrust bearing	DIA52W-15	1	Lens head screw 4x20	DIA52W-86	2
Clutch spring	DIA52W-16	1	Lustre terminal	DIA52W-88	1
Bevel gear	DIA52W-17	1	Lens head screw M3,5x4	DIA52W-89	1
Tool bit driver	DIA52W-18	1	Reducer 3/4"	DIA52W-92	1
Roller 4x11,8	DIA52W-19	14	Hose coupling 3/4"	DIA52W-93	1
Roller 4x19,8	DIA52W-20	10	Plastic tube	DIA52W-94	1
Ball bearing	DIA52W-21	1	PVC fabric braided hose	DIA52W-95	1
Space hull	DIA52W-22	1	Hose clamp	DIA52W-96	2
Tube	DIA52W-23	1	Protective tube	DIA52W-97	1
Connecting fitting	DIA52W-27	1	Cord, plug and PRCD	DIA52W-98k	1
Cylinder housing	DIA52W-28	1	Cord for PRCD	DIA52W-98a	0
Metering cone, assembled	DIA52W-29	1	PRCD circuit breaker	DIA52W-98b	0
O-ring seal 10x3,5	DIA52W-30	1	Cord, plug without PRCD	DIA52W-98c	0
Screw joint	DIA52W-31	1	Cord sleeve dia. 10mm	DIA52W-99	1
Case flange	DIA52W-32	1	Ball bearing	DIA52W-300	1
Sealing ring	DIA52W-33	1	Motor housing	DIA52W-301	1
Hexagon nut M16x1,5	DIA52W-34	1	Ventilation insert, right	DIA52W-302	1
Cheese head screw M5x8	DIA52W-35	1	Ventilation insert, left	DIA52W-303	1
V-ring seal	DIA52W-36	1	Ball valve, assembled	DIA52W-304k	1
O-ring seal 26x2	DIA52W-37	1	Ball valve lever, assembled	DIA52W-305k	0
Plain washer	DIA52W-38	1	Retaining ring	DIA52W-306	1
Ball bearing	DIA52W-39	1	Washer M7	DIA52W-307	1
Retaining ring	DIA52W-40	1	Fixing bracket	DIA52W-308	1
Washer	DIA52W-41	1	Insulating housing	DIA52W-309	1
Ball bearing	DIA52W-43	1	Field, 230V	DIA52W-310	1
Rubber sleeve	DIA52W-44	1	Armature, 230V	DIA52W-311	1
Grooved pin	DIA52W-47	4	Insulating sleeve	DIA52W-312	1
Lens head screw 4x48	DIA52W-48	2	DIA52W nameplate	DIA52W-313	1
Motor cover	DIA52W-51	1	DUSS DIA52W sticker	DIA52W-314	2
Lens head screw M4x20	DIA52W-52	4	Brush holder	DIA52W-315	2
Bevel gear pinion	DIA52W-53	1	Carbon brush AB with wire strand	DIA52W-316	1
Gear wheel	DIA52W-54	1	Carbon brush	DIA52W-317	1
Ball bearing	DIA52W-56	1	Electronics ass'y	DIA52W-318	1
Needle bush	DIA52W-57	1	Protective ground wire connector	DIA52W-319	1
Needle bush	DIA52W-58	1	Switch	DIA52W-320	1

Spare part list

DIA 52 W diamond core drill

DUSS

Description	Order-No.	Quantity
Damper cylinder housing	DIA52W-321	1
Switch handle	DIA52W-322	1
Fitting for the diodes	DIA52W-323	1
Nut M12	DIA52W-324	1
Cheese head screw M5x25	DIA52W-325	4
Spacer	DIA52W-326	4

Description	Order-No.	Quantity
Side handle	DIA52W-327	1
O-ring seal 8x3	DIA52W-328	1
Capacitor	DIA52W-329	1

DUSS

DIA 52 W

