

Spare part list

P 26 C combi hammer

DUSS

Description	Order-No.	Quantity
Clamping collar, assembled	P26C-1K	0
Side handle	P26C-1	1
Nut M10	P26C-2	1
Clamping collar	P26C-3	1
Star knob M5	P26C-4	1
Hexagon nut M5	P26C-5	1
Depth stop	P26C-6	1
Cap	P26C-7	1
Dust guard	P26C-8	1
Locking sleeve	P26C-9	1
Retaining ring SW 18	P26C-10	2
Ring	P26C-11	1
Steel sleeve	P26C-12	1
Retainer	P26C-13	1
Spring	P26C-14	1
Spring	P26C-15	1
Aluminium sleeve	P26C-16	1
Ball dia. 7mm	P26C-17	2
Chuck	P26C-18	1
Chuck, assembled	P26C-18k	0
Cheese head screw M5x20	P26C-19	4
Front cover	P26C-20	1
Gasket	P26C-21	1
Dust seal	P26C-22	1
Ram	P26C-23	1
Friction bearing	P26C-24	1
O-ring seal 23x5	P26C-25	2
Seal	P26C-26	1
Tool bit driver	P26C-27	1
Sleeve bearing	P26C-28	1
Retaining ring	P26C-29	1
Friction sleeve	P26C-30	1
Clutch spring	P26C-31	1
Pin	P26C-32	2
Roller 3x9,8	P26C-33	3
Safety clutch	P26C-34	1
Clutch dog	P26C-35	1
Retaining ring	P26C-36	1
O-ring seal 43x4	P26C-37	1
Sleeve bearing	P26C-38	1
Damper washer	P26C-39	3
Circlip	P26C-40	2
Cylinder	P26C-41	1
Striker	P26C-42	1
Piston ring	P26C-43	1
Piston ring	P26C-44p	1
Piston pin	P26C-45	1
Spring lock washer	P26C-46	2
Piston	P26C-47	1
Piston, assembled	P26C-47k	0

Description	Order-No.	Quantity
Connecting rod	P26C-48	1
Needle bush	P26C-49	1
Cylinder housing	P26C-50	1
Screw 4x27	P26C-51	6
Roller 5x10	P26C-52	1
Shaft	P26C-53	1
O-ring seal 10x1,5	P26C-54	1
Upper cover	P26C-55	1
Lens head screw 3,5x20	P26C-56	4
Ball dia. 4mm	P26C-57	1
Spring	P26C-58	1
Countersunk head screw M5x8	P26C-59	1
Cylinder housing gasket	P26C-60	1
Crank shaft	P26C-61	1
Ball bearing	P26C-62	1
Gear wheel	P26C-63	1
Washer	P26C-64	1
Sleeve bearing	P26C-65	2
Gear wheel	P26C-66	1
Ball bearing	P26C-67	1
Gear plate	P26C-68	1
Copper washer M5	P26C-69	6
Cheese head screw M5x16	P26C-70	6
V-ring seal	P26C-71	1
O-ring seal 18x2	P26C-72	1
Plain washer	P26C-73	1
Rubber sleeve	P26C-74	1
Ball bearing	P26C-75	1
Retaining ring	P26C-76	1
Armature, 230V	P26C-77	1
Ball bearing	P26C-78	1
Rubber sleeve	P26C-79	1
Lens head screw 4x48	P26C-80	2
Baffle plate	P26C-81	1
Field, 230V	P26C-82	1
Motor housing	P26C-83	1
Lens head screw 3,5x30	P26C-84	2
Change lever	P26C-85	1
Raised countersunk screw M4x10	P26C-86	1
P26C nameplate	P26C-87	1
Brush holder	P26C-88	2
Lens head screw 3x10	P26C-89	4
Carbon brush	P26C-90	2
Motor cover	P26C-91	1
Lens head screw 4x14	P26C-92	6
DUSS P26C sticker	P26C-93	2
Capacitor	P26C-94	1
Damper cylinder housing	P26C-95	1
Switch	P26C-96	1
Switch protection cap	P26C-97	1

Spare part list

P 26 C combi hammer



Description	Order-No.	Quantity
Damper motor housing	P26C-98	1
Switch handle	P26C-99	1
Spacer	P26C-100	4
Lens head screw 5x30	P26C-101	4
Lens head screw 4x20	P26C-102	2

Description	Order-No.	Quantity
Cord sleeve	P26C-103	1
Cord clamp	P26C-104	1
Cord and plug	P26C-105	1
Thrust washer	P26C-106	1

DUSS

P 26 C

