

Spare part list

P 26 C combi hammer

DUSS

Description	Order-No.	Quantity	Description	Order-No.	Quantity
Clamping collar, assembled	P26C-1K	0	Connecting rod	P26C-48	1
Side handle	P26C-1	1	Needle bush	P26C-49	1
Nut M10	P26C-2	1	Cylinder housing	P26C-50	1
Clamping collar	P26C-3	1	Screw 4x27	P26C-51	6
Star knob	P26C-4	1	Roller 5x10	P26C-52	1
Hexagon nut M5	P26C-5	1	Shaft	P26C-53	1
Depth stop	P26C-6	1	O-ring seal 12x1,5	P26C-54	1
Cap	P26C-7	1	Upper cover	P26C-55	1
Dust guard	P26C-8	1	Lens head screw 3,5x20	P26C-56	4
Locking sleeve	P26C-9	1	Ball dia. 4mm	P26C-57	1
Retaining ring RW 18	P26C-10	2	Spring	P26C-58	1
Ring	P26C-11	1	Countersunk head screw M5x8	P26C-59	1
Steel sleeve	P26C-12	1	Cylinder housing gasket	P26C-60	1
Retainer	P26C-13	1	Crank shaft	P26C-61	1
Spring	P26C-14	1	Ball bearing	P26C-62	1
Spring	P26C-15	1	Gear wheel	P26C-63	1
Aluminium sleeve	P26C-16	1	Washer	P26C-64	1
Ball dia. 7mm	P26C-17	2	Sleeve bearing	P26C-65	2
Chuck	P26C-18	1	Gear wheel	P26C-66	1
Chuck, assembled	P26C-18k	0	Ball bearing	P26C-67	1
Cheese head screw M5x20	P26C-19	4	Gear plate	P26C-68	1
Front cover	P26C-20	1	Copper washer M5	P26C-69	6
Gasket	P26C-21	1	Cheese head screw M5x16	P26C-70	6
Dust seal	P26C-22	1	V-ring seal	P26C-71	1
Ram	P26C-23	1	O-ring seal 18x2	P26C-72	1
Friction bearing	P26C-24	1	Plain washer	P26C-73	1
O-ring seal 23x5	P26C-25	2	Rubber sleeve	P26C-74	1
Seal	P26C-26	1	Ball bearing	P26C-75	1
Tool bit driver	P26C-27	1	Retaining ring	P26C-76	1
Sleeve bearing	P26C-28	1	Armature, 230V	P26C-77	1
Retaining ring	P26C-29	1	Ball bearing	P26C-78	1
Friction sleeve	P26C-30	1	Rubber sleeve	P26C-79	1
Clutch spring	P26C-31	1	Lens head screw 4x48	P26C-80	2
Pin	P26C-32	2	Baffle plate	P26C-81	1
Roller 3x9,8	P26C-33	3	Field, 230V	P26C-82	1
Safety clutch	P26C-34	1	Motor housing	P26C-83	1
Clutch dog	P26C-35	1	Lens head screw 3,5x30	P26C-84	2
Retaining ring	P26C-36	1	Change lever	P26C-85	1
O-ring seal 43x4	P26C-37	1	Raised countersunk screw M4x10	P26C-86	1
Sleeve bearing	P26C-38	1	P26C nameplate	P26C-87	1
Damper washer	P26C-39	3	Brush holder	P26C-88	2
Circlip	P26C-40	2	Lens head screw 3x10	P26C-89	4
Cylinder	P26C-41	1	Carbon brush	P26C-90	2
Striker	P26C-42	1	Motor cover	P26C-91	1
Piston ring	P26C-43	1	Lens head screw 4x14	P26C-92	6
Piston ring	P26C-44p	1	DUSS P26C sticker	P26C-93	2
Piston pin	P26C-45	1	Capacitor	P26C-94	1
Spring lock washer	P26C-46	2	Damper cylinder housing	P26C-95	1
Piston	P26C-47	1	Switch	P26C-96	1
Piston, assembled	P26C-47k	0	Switch protection cap	P26C-97	1

Spare part list

P 26 C combi hammer

DUSS

Description	Order-No.	Quantity
Damper motor housing	P26C-98	1
Switch handle	P26C-99	1
Spacer	P26C-100	4
Lens head screw 5x30	P26C-101	4
Lens head screw 4x20	P26C-102	2
Cord sleeve	P26C-103	1

Description	Order-No.	Quantity
Cord clamp	P26C-104	1
Cord and plug	P26C-105	1
Washer	P26C-106	1

DUSS

P 26 C

